Skandinavisk Orgelcentrum

Unpacking

Danhild VARIO

- the classical organ for everyone

Electrical height adjustable keyboards! Electrical height adjustable organ bench! Full 30-note pedal board! 32 speaking stops!

Danish design and quality - all the way!

Manufacturer: Skandinavisk Orgelcentrum

Address: Ribevej 38, Oedsted

DK-7100 Vejle

Country: Denmark

Telephones: +45 75 86 41 00 (Sales) +45 76 65 60 90 (Service Support)

E-mail: inform@churchorgans.com

Service: service@churchorgans.com

Websites: www.churchorgans.com www.kirchenorgeln.eu www.kirkeorgel.dk

Version: 1.0

Date: July 2015

Legal right to changes without notice !!!

© 2015 Skandinavisk Orgelcentrum

All rights reserved. Nothing in this publication may be reproduced, stored in a data file or made public in any form or in any way either electronically, mechanically by way of photocopying, recording or in any other way without the prior written permission of *Skandinavisk Orgelcentrum*.



FRONT of Boxed Danhld VARIO

Prerequisites needed:


- 1) Screw machine
- 2) Cross screw bit
- 3) Torx Bit
- 4) Blankets
- 5) One person to help

Nice to have:

One pallet




Unscrew Top (all screws)



Unscrew front plate (buttom and both sides)

You do not need to unscrew Top screws for front plate



Lift off front plate






Unscrew screws from rear plate

(you only need to unscrew screws in left side all way up)


Let your helper hold and support the two side pieces



Unscrew left side piece from buttom plate
Let your helper hold and support
the side piece



Take off the blue strap



Take off tape and remove the organ bench



Prepare to remove the rear plate



Unscrew the rear plate (you do not need to unscrew the top screws)



Unscrew the right side piece



The organ and pedal keyboard are now left



Remove Pedal keyboard
Be careful when you slide it out
not to scratch....
(put a blanket in front)






Unscrew and remove the supporter plate





Unscrew and remove the wood blocks



Place a pallet to the left side as shown on the above picture



Prepare tilting the organ



Tilt the organ






Put down the organ to horizontal position

Do **NOT** lift under the keyboards !!!



Always beware:
Do **NOT** lift under the keyboards when moving the organ !!

Place the pedal keyboard under the organ console (see further instruction in User Manual)



Place Organ bench



Connect the power for the organ bench to the power outlet in the right side of the organ console

